



Plume SuperPod Install Instructions

1. Download the Plume app to your phone.
2. Open the app and sign up to start setup.
3. Disconnect your router or GigaCenter from the modem cable and reconnect your SuperPod to the modem cable.
4. Set up your new Wi-fi name and password.
*When setting your pod password, we recommend using the same password as your router or GigaCenter so you don't have to reset all of your devices with the new password. Make sure capitalization of letters is consistent.
5. Plug additional pods in different rooms and follow app guidelines.
6. Connect your devices.

Please call us with any questions you may have 866-255-9378.